

Assembly of clock movements 800433 & 800434

- 1. If the supplied hanger is required, place this in position over the spindle thread followed by the rubber washer before passing the spindle through your clock face.**
- 2. Place the plain washer on the front of the clock face followed by the securing nut which should be secure but not over tightened.**
- 3. Push the hour hand into position on the shaft first followed by the minute hand and finally the second hand**
- 4. When adjusting the clock to the correct time, please use the small wheel on the back of the movement and do not move the hands manually.**

N.B. A 1.5V Battery AA (LR6) will be required to power your clock We advise not using alkaline type batteries. Pack of 4 available (309018)